


SPACESEAL 501

Remote stack with Expanding Jamb as the closure



P-C Formula = Opening Width - 170mm / number of panels - 270mm = P-C

Panel width = Opening width (- 170) / number of panels

Stack Formula = Number of Panels x 85mm + 40mm (minimum distance)

<p>GENERAL TOLERANCES UNLESS OTHERWISE SPECIFIED</p> <p>0 = +/- 0.5 0.0 = +/- 0.1 0.00 = +/- 0.05</p>		<p>DATE: 11/02/2014</p>	
<p>DESIGNER</p> <p>TONY W</p>	<p>REV</p> <p>3</p>	<p>SCALE</p> <p>AS SHOWN</p>	<p>DESCRIPTION</p> <p>Remote stack with expanding jamb as the closure</p>
<p>ORDERED</p> <p>1</p>	<p>SHEET</p> <p>1</p>	<p>JOB NAME</p> <p>501 Formula Details</p>	<p>PART NUMBER</p>
<p>TRANS-SPACE MANAGING SPACE WITH OPENABLE WALLS AND DOORS</p>			

TRANSSPACE LTD. THESE DRAWINGS AND PRODUCTS MADE THEREFROM ARE SUBJECT TO COPYRIGHT UNDER THE NEW ZEALAND COPYRIGHT ACT 1994 AND NEITHER THE DRAWINGS OR PRODUCTS MADE THEREFROM MAY BE REPRODUCED IN ANY MATERIAL FORM OR MODIFIED IN ANYWAY WITHOUT THE WRITTEN APPROVAL OF TRANSSPACE LTD.